



STOP LEAKS

Helps stop minor leaks in main bearing seals, pan, and valve cover gaskets. Helps prevent costly repairs.

- Effectively Stops Leaks in Seals & Gaskets
- Mixes With Crankcase Oil
- For Auto & Small Truck Engines
- Conditions Seals


*For more information please contact your
ABRO sales representative.*

E0-414

ENGINE OIL STOP LEAK

PRODUCT SHEET

06/2022



Part No.	Fill	Pcs/Case
E0-414	12oz/354mL	12/CASE